

DIO24 Firmware Utility(PC) User Manual

◆ Preparation


1. 1x PC Windows 7 or more
2. 1x DIO24 Device
3. 1x A wireless router
4. 2x Network cable
5. 1x DIO24 firmware update tool file.

◆ system Connections

1. Connect the device to the computer in one of the following ways.


method one:

- Connect the device network port to the router via a network cable.
- The computer is connected to the router via a network cable.



Method two:


- Connect the device network port to the router via a network cable.
- The computer is connected to the router via wifi.




◆ update operation

1. Turning on the software and start updating software.


2. Select the Network Interface




3. Click the Scan button to search for devices.





4. Select the device and click the Update button to enter the update interface.



5. Click on the Begin Program to start the update.



6. Please wait for the update to complete, if the updated device is a host or an extension, it will enter the DSP update. This process is fully automated, please wait a moment.



7. When the update is complete, you can shut down the software after waiting for the device to reboot.